

C150 Maneuvers

Slow Flight

1. Carb Heat On
2. Power to 1500
3. Flaps to 20*
4. Maintain Altitude by Adding Power
5. Recover by turning carb heat off, adding full power and flaps up

Power-Off Stall

1. Carb Heat On
2. Power to 1500
3. Flaps to 20*
4. Maintain altitude to bleed off Airspeed
5. Once at 55-60 MPH, Power to Idle
6. Pitch Down Slightly to Simulate approach to landing
7. Pull up until full stall
8. Recovery: Pitch down, turn carb heat off, add full power, flaps up

Power-On Stall

1. Carb Heat On
2. Power to Idle
3. Hold altitude to bleed off airspeed
4. At 55-60 MPH turn carb heat off, add full power, pitch up to stall
5. Recovery: Pitch Down, decrease power

Emergency Decent

1. Carb Heat On
2. Power to Idle
3. Flaps to desired setting (0-20*)
4. 30-45* bank
5. Pitch for Flap Speed or Maneuvering Speed
6. Level out 50 ft. above desired altitude